



	7" FROM DOOR EDGE 1.25" FROM TOP OF DOOR HANDLE
	3" IN FROM HOOD EDGE 6.5" UP FROM WHEEL W
<p>PSIDE</p> 	10" FROM EDGE OF DOOR USDOT ON TOP CA ON BOTTOM STARS FACE FORWARD CENTER IN AREA LEVEL 3.5" IN FROM WHEELW PLACE NUMBER
<p>DSIDE</p> 	10" FROM EDGE OF DOOR USDOT ON TOP CA ON BOTTOM STARS FACE FORWARD CENTER IN AREA LEVEL 3.5" IN FROM WHEELW PLACE NUMBER
	AIRDAM DECAL PLACEMENT 12" DOWN FROM TOP CENTER DECAL SIDE TO SIDE
 PANTONE 1665 C Print media: Substance RS-275 / PL-3150 Gloss	TEXT FONT: PP Mori Semi Bold



Photos of ALL sides BEFORE + AFTER supplied to WestAir upon completion of work, submitting invoice*

Proofs must have the following:

Removal of all NON-ESSENTIAL vinyl stickers (EXCL. Ryder/Gibbs#S)

Exact measurement of vinyl stickers and their exact placement/measurements on the asset

Color: Pantone 1665C

Material Type: Substance RS-275 / PL-3150 gloss

UN or NFPA Diamond + Text (Confirmed with on-site POC*)

Font Guidelines:

PP Mori Semi Bold, unless otherwise stated*

Asset Numbers = No. 123 or stacked where necessary*

@westairgases in black on white background

Family-owned & operated since 1970. ("Since 1970" in orange, everything else, incl. period in black*)

Placarded Vehicles 101:

The Railroad Caution Stickers must be on ALL placarded vehicles

The Wide-Turn Caution Stickers must be on ALL tractor/trailer combos (On trailer, see guidelines below*)

TRACTORS

Freightliners

Leave Ryder/Gibbs stickers, DOT, etc. -- Remove non-essential stickers

Remove air dam/hood vinyls – DO NOT PRODUCE/INSTALL, update proof*

International

Needs exact placement/measurements

See rules above*

Peterbilt

Needs exact placement/measurements

See rules above*