


	<p>16.5" FROM FRONT DOOR EDGE</p> <p>3" FROM BACK DOOR EDGE</p> <p>1.25" FROM TOP OF DOOR HANDLE</p>
	<p>3" IN FROM HOOD EDGE 6.5" UP FROM WHEEL W</p>
<p>PSIDE</p> 	<p>10" FROM EDGE OF DOOR USDOT ON TOP CA ON BOTTOM</p> <p>STARS FACE FORWARD CENTER IN AREA LEVEL</p> <p>3.5" IN FROM WHEELW PLACE NUMBER</p>
<p>DSIDE</p> 	<p>10" FROM EDGE OF DOOR USDOT ON TOP CA ON BOTTOM</p> <p>STARS FACE FORWARD CENTER IN AREA LEVEL</p> <p>3.5" IN FROM WHEELW PLACE NUMBER</p>
	<p>AIRDAID DECAL PLACEMENT 12" DOWN FROM TOP</p> <p>CENTER DECAL SIDE TO SIDE</p>
	<p>PANTONE 1665 C</p>
<p>Print media: Substance RS-275 / PL-3150 Gloss</p>	<p>TEXT FONT: PP Mori Semi Bold</p>

Removal of all NON-ESSENTIAL vinyl stickers (EXCL. Ryder/Gibbs#S)



Photos of ALL sides BEFORE + AFTER supplied to WestAir upon completion of work, submitting invoice*

Proofs must have the following:

Removal of all NON-ESSENTIAL vinyl stickers (EXCL. Ryder/Gibbs#S)

Exact measurement of vinyl stickers and their exact placement/measurements on the asset

Color: Pantone 1665C

Material Type: Substance RS-275 / PL-3150 gloss

UN or NFPA Diamond + Text (Confirmed with on-site POC*)

Font Guidelines:

PP Mori Semi Bold, unless otherwise stated*

Asset Numbers = No. 123 or stacked where necessary*

@westairgases in black on white background

Family-owned & operated since 1970. ("Since 1970" in orange, everything else, incl. period in black*)

Placarded Vehicles 101:

The Railroad Caution Stickers must be on ALL placarded vehicles

The Wide-Turn Caution Stickers must be on ALL tractor/trailer combos (On trailer, see guidelines below*)

TRACTORS

Freightliners

Leave Ryder/Gibbs stickers, DOT, etc. -- Remove non-essential stickers

Remove air dam/hood vinyls – DO NOT PRODUCE/INSTALL, update proof*

International

Needs exact placement/measurements

See rules above*

Peterbilt

Needs exact placement/measurements

See rules above*