



<p>30"</p> <p>7"</p>	<p>3.5" FROM DOOR HANDLE SIDE TO SIDE</p> <p>8.5" FROM BOTTOM OF DOOR SEAM</p>
<p>21"</p> <p>3" (866) westair</p>	<p>CENTER ABOVE WHEEL</p> <p>2" UP</p>
<p><b>PSIDE</b></p> <p>19.25"</p> <p>2" USDOT 984817</p> <p>2" CA 12735</p> <p>12"</p> <p>5.65 in</p> <p>3.00 in</p> <p>2" No. XXX</p> <p>9.5"</p>	<p>3.5" FROM EDGE USDOT ON TOP</p> <p>CA ON BOTTOM OF DOOR SEAM</p> <p>STARS FACE FORWARD</p> <p>1" FROM HOOD SEAM</p> <p>3.5" IN FROM WHEELW</p> <p>PLACE NUMBER</p>
<p><b>DSIDE</b></p> <p>19.25"</p> <p>2" USDOT 984817</p> <p>2" CA 12735</p> <p>12"</p> <p>5.65 in</p> <p>3.00 in</p> <p>2" No. XXX</p> <p>9.5"</p>	<p>USDOT ON TOP</p> <p>CA ON BOTTOM OF DOOR SEAM</p> <p>STARS FACE FORWARD</p> <p>1" FROM HOOD SEAM</p> <p>3.5" IN FROM WHEELW</p> <p>PLACE NUMBER</p>
<p>PANTONE 1665 C</p> <p>Print media: Substance RS-275 / PL-3150 Gloss</p>	<p><b>TEXT FONT:</b></p> <p>PP Mori</p> <p>Semi Bold</p>
<p>5" westair</p> <p>22"</p> <p>4" </p> <p>7.5"</p> <p>2" (866) westair</p> <p>14.4"</p> <p>2" No. 518</p> <p>9"</p> <p>2" @westairgases</p> <p>14.5"</p> <p>8" </p>	<p>PLACE 3.5" OFF</p> <p>EDGE</p> <p>CENTER IN</p> <p>SLATS</p>



Photos of ALL sides BEFORE + AFTER supplied to WestAir upon completion of work, submitting invoice\*

Proofs must have the following:

Removal of all NON-ESSENTIAL vinyl stickers (Incl. Ryder/Gibbs, DOT, etc.)

Exact measurement of vinyl stickers and their exact placement/measurements on the asset

Color: Pantone 1665C

Material Type: Substance RS-275 / PL-3150 gloss

UN or NFPA Diamond + Text (Confirmed with on-site POC\*)

Font Guidelines:

PP Mori Semi Bold, unless otherwise stated\*

Asset Numbers = No. 123 or stacked where necessary\*

@westairgases in black on white background

Family-owned & operated since 1970. ("Since 1970" in orange, everything else, incl. period in black\*)

Placarded Vehicles 101:

The Railroad Caution Stickers must be on ALL placarded vehicles

The Wide-Turn Caution Stickers must be on ALL tractor/trailer combos (On trailer, see guidelines below\*)

## TRACTORS

### Freightliners

Leave Ryder/Gibbs stickers, DOT, etc. -- Remove non-essential stickers

Remove air dam/hood vinyls – DO NOT PRODUCE/INSTALL, update proof\*

### International

Needs exact placement/measurements

See rules above\*

### Peterbilt

Needs exact placement/measurements

See rules above\*