


BACK DOOR



<p>DRIVER SIDE</p>	
<p>PASSENGER SIDE</p>	
<p>PANTONE 1665 C</p> <p>Print media: Substance RS-275 / PL-3150 Gloss</p>	<p>TEXT FONT: PP Mori Semi Bold</p>
	<p>PLACE DECALS 3.5" FROM EDGE OF DOORS.</p>



Photos of ALL sides BEFORE + AFTER supplied to WestAir upon completion of work, submitting invoice*

Proofs must have the following:

Removal of all NON-ESSENTIAL vinyl stickers (EXCL. Ryder/Gibbs#S)

Exact measurement of vinyl stickers and their exact placement/measurements on the asset

Color: Pantone 1665C

Material Type: Substance RS-275 / PL-3150 gloss

UN or NFPA Diamond + Text (Confirmed with on-site POC*)

Font Guidelines:

PP Mori Semi Bold, unless otherwise stated*

Asset Numbers = No. 123 or stacked where necessary*

@westairgases in black on white background

Family-owned & operated since 1970. ("Since 1970" in orange, everything else, incl. period in black*)

Placarded Vehicles 101:

The Railroad Caution Stickers must be on ALL placarded vehicles

The Wide-Turn Caution Stickers must be on ALL tractor/trailer combos (On trailer, see guidelines below*)

TRAILERS

UN or NFPA Diamond + Text Req'd on ALL assets

Four corners of text on back lift gates/hatches/doors

Family tagline (Top/left)

US Flag (Top/right)

UN or NFPA Diamond + Text (Bottom/left)

No. 123 on top of @westairgases

Damaged upon inspection, installation? Add to "Maintenance" list to be re-visited post-completion*

DOT Conspicuity tape included on ALL proofs; to be installed on "as-needed" basis by on-site POCs.

Only install/remove if needed, otherwise leave alone.