








3.5"	
	No. XXX
(866) westair	@westairgases
	

		EQ DISTANCE BETWEEN DOOR HANDLE AND MIRROR 5.5" BODY LINE TO BOTTOM OF LOGO
<p>PSIDE</p> 		.75" FROM EDGE OF DOOR .5" UP FROM EMBLEM USDOT ON TOP CA ON BOTTOM STARS FACE FORWARD CENTER IN AREA LEVEL 2" UP FROM BODY LINE
<p>DSIDE</p> 		.75" FROM EDGE OF DOOR .5" UP FROM EMBLEM USDOT ON TOP CA ON BOTTOM STARS FACE FORWARD CENTER IN AREA LEVEL 2" UP FROM BODY LINE
 <p>PANTONE 1665 C</p> <p>Print media: Substance RS-275 / PL-3150 Gloss</p>		TEXT FONT: PP Mori Semi Bold
		SLAT SIZE MAY VARY PLEASE SIZE ACCORDINGLY DO NOT SIZE BIGGER THAN SHOWN



Photos of ALL sides BEFORE + AFTER supplied to WestAir upon completion of work, submitting invoice*

Proofs must have the following:

Removal of all NON-ESSENTIAL vinyl stickers (EXCL. Ryder/Gibbs#S)

Exact measurement of vinyl stickers and their exact placement/measurements on the asset

Color: Pantone 1665C

Material Type: Substance RS-275 / PL-3150 gloss

UN or NFPA Diamond + Text (Confirmed with on-site POC*)

Font Guidelines:

PP Mori Semi Bold, unless otherwise stated*

Asset Numbers = No. 123 or stacked where necessary*

@westairgases in black on white background

Family-owned & operated since 1970. ("Since 1970" in orange, everything else, incl. period in black*)

Placarded Vehicles 101:

The Railroad Caution Stickers must be on ALL placarded vehicles

The Wide-Turn Caution Stickers must be on ALL tractor/trailer combos (On trailer, see guidelines below*)

Isuzu

Lift Gates

Black = White Text + Orange Logo

Silver/white = Black Text + Orange Logo

Caution stickers balanced equally/centered between elements on bottom of lift gate – incl. measurements

DOT Conspicuity tape included on ALL proofs; to be installed on "as-needed" basis by on-site POCs. Only install/remove if needed, otherwise leave alone.

Include mudflaps in proofs where possible*